



CATLINK

SR INTERFACE (PIONEER) ADAPTER

INFRARED REMOTE CONTROL DISTRIBUTION

The Catlink SR Interface Adapter converts the emitter drive signal from Catlink or other industry standard emitter drive outputs and converts it to a signal compatible with Pioneer equipment SR interface inputs.



PART# CL-SRADP

Equipped with two leads both terminated with industry standard 3.5mm phone jack mono plugs for direct connection source equipment such as to an CL-EMADP, CL-EMOUT6EL or IROUT and direct connection to SR interface input.

Provided with case flanges for screwing to wall or bracket.

Specifications

<i>Part Number</i>	CL-SRADP
<i>Lead lengths</i>	80cm
<i>Dimensions (including flanges)</i>	72mm (W) x 37mm (D) x 26.5mm (H)

ControlPlus Products
A DIVISION OF ACTIVE TECHNOLOGIES LIMITED

PO BOX 125, SILVERDALE, AUCKLAND, NEW ZEALAND
www.controlplus.co.nz

RELEASE SPECIFICATION

ACTIVE TECHNOLOGIES LIMITED RESERVES THE RIGHT TO CHANGE SPECIFICATIONS WITHOUT NOTICE AT ANY TIME.

DOC REV 1 19/09/06